PARENTESIT

Finiture Materialien Finitions Acabados 仕上げ Metalli Metals Metalle Métal Metal



V39 - matt

Balder 3

Arper grade
CHAIRS: I
SOFAS: I
PANELS: I





B102635

Canvas 2



Kvadrat's Canvas 2 has been awarded the EU Ecolabel

Arper grade
CHAIRS: D
SOFAS: F
PANELS: D





Divina 3



Kvadrat's Divina 3 has been awarded the EU Ecolabel

Arper grade CHAIRS: **G** SOFAS: **I** PANELS: **G**



Divina MD



Kvadrat's Divina MD has been awarded the EU Ecolabel

Arper grade CHAIRS: **G** SOFAS: **I** PANELS: **G**



Divina Melange 3



Kvadrat's Divina Melange 3 has been awarded the EU Ecolabel

Arper grade CHAIRS: **G** SOFAS: **I** PANELS: **G**



Field 2



Kvadrat's Field 2 has been awarded the EU Ecolabel

Arper grade
CHAIRS: B
SOFAS: C
PANELS: B



Fiord 2 (EU Ecolabel)



Kvadrat's Fiord 2 has been awarded the EU Ecolabel

Arper grade
CHAIRS: F
SOFAS: F
PANELS: F



Floyd

Arper grade
CHAIRS: C
SOFAS: C
PANELS: C



Hallingdal 65 (EU Ecolabel)



Kvadrat's Hallingdal 65 has been awarded the EU Ecolabel

Arper grade CHAIRS: G SOFAS: G G PANELS: G(*)





HA00173

HA00350

HA00526














































Not available for Paravan collection

Jaali



Kvadrat's Jaali has been awarded the EU Ecolabel

Arper grade CHAIRS: SOFAS: PANELS: G G G







Re-wool



Kvadrat's Re-wool has been awarded the EU Ecolabel

Arper grade
CHAIRS: E
SOFAS: E
PANELS: E



Remix 3 (EU Ecolabel)



Kvadrat's Remix 3 has been awarded the EU Ecolabel

Arper grade
CHAIRS: C
SOFAS: D
PANELS: C





Remix 3 (EU Ecolabel)



Kvadrat's Remix 3 has been awarded the EU Ecolabel

Arper grade
CHAIRS: C
SOFAS: D
PANELS: C



(*) RX00113 - RX00223: only for the cushions Owl, Lines, Pleats e Gego.

Revive 1

Arper grade
CHAIRS: **B**SOFAS: **B**PANELS: **B**



Steelcut 3



Kvadrat's Steelcut 3 has been awarded the EU Ecolabel

Arper grade CHAIRS: **G** SOFAS: **H** PANELS: **G**



Steelcut Trio 3



Kvadrat's Steelcut Trio 3 has been awarded the EU Ecolabel

Arper grade
CHAIRS: G
SOFAS: H
PANELS: G



Tonus 4



Kvadrat's Tonus 4 has been awarded the EU Ecolabel

Arper grade
CHAIRS: F
SOFAS: G
PANELS: F





T300974

Vidar 4



Kvadrat's Vidar 4 has been awarded the EU Ecolabel

Arper grade
CHAIRS: J
SOFAS: J
PANELS: J





Jet

Arper grade
CHAIRS: A
SOFAS: A
PANELS: A



(*) Not available for Cila and Cila Go collections





Jet

Arper grade
CHAIRS: A
SOFAS: A
PANELS: A



(*) Not available for Cila and Cila Go collections

Main Line Flax

Arper grade
CHAIRS: C
SOFAS: C
PANELS: C



Phoenix

Arper grade
CHAIRS: A
SOFAS: A
PANELS: A



Synergy

Arper grade
CHAIRS: C
SOFAS: C
PANELS: C



Synergy

Arper grade
CHAIRS: C
SOFAS: C
PANELS: C



Urban

Arper grade
CHAIRS: B
SOFAS: B
PANELS: B



maharam Messenger

Arper grade
CHAIRS: D
SOFAS: D
PANELS: D





Istituito nel 1992, il marchio comunitario di qualità ecologica o Ecolabel, il cui logo è rappresentato da un fiore, è uno speciale sistema di certificazione creato per aiutare i consumatori europei a scegliere prodotti e servizi più ecologici e più rispettosi dell'ambiente.

Estabilished in 1992, the EU Eco-label "Flower" is a unique certification scheme aimed to help European consumers distinguish greener, more environmentally friendly, products and services.

Hinter der "Blume", dem 1992 ins Leben gerufenen EU-Umweltzeichen, steckt ein einzigartiges Zertifizierungssystem, das dem europäischen Verbraucher das Erkennen umweltfreundicherer Produkte und Dienstleistungen erleichtern soll.

Ètabli en 1992, le label écologique de l'EU symbolisé par la "Fleur" est un système d'homologation unique destiné à aider les consommateurs européèns à discerner les produits et services plus verts et plus favorables à environnement.

Creada en 1992, la etiqueta ecològica de la UE, también conocida come "la flor", constituye un sistema de certification unico, cuyo objetivo es ayudar a los consumidores europeos a identificar los productos y servicios más ecologicos y respetuosos del medio ambiente.

Care instructions

Fabrics:

It is important that fabrics are cleaned regularly in order to keep them looking their best and extend their life. Powder and dirt can cause wear and tear on fabrics and as such we advise that you clean them using a low-pressure vacuum cleaner, preferably once a week.

Non-greasy stains can be removed by delicately dabbing them with a clean cloth that won't leave any lint or a sponge that has been soaked in clean, warm water then thoroughly squeezed out. If necessary, you can then soak with soapy water or water with liquid washing up detergent added (see formulas). Once this is done, soak the surface with clean, tepid water.

For greasy stains, use a dry stain remover. Ensure that you comply with the manufacturer's instructions as closely as possible. If you have any doubts, test the cleaning product on a discreet area in order to check its effect. Wait for at least 24 hours to see if any problems arise.

<u>Formulas</u>: The soapy solution consists of ½ deciliter soap flakes per liter of hot water, which must then be cooled before use. The solution with dishwashing liquid is made up of max 1 teaspoon of detergent per every liter of water. If you use concentrated products, pour only a few drops into each liter of product.

Coated fabrics:

Regularly dust using a microfibre cloth. In the event of stains, clean using a cloth that has been dampened using tepid water or water with some neutral soap in it. Do not used abrasive products, ethyl alcohol and solvent-based detergents. If you have any doubts, test the cleaning product on a discreet area in order to check its effect. Wait for at least 24 hours to see if any problems arise.

Structural mesh in knitted fabric:

Made to Arper's technical specifications with post-consumption recycled polyester yarns, the knitted fabric mesh is soft and comfortable. The particular structure makes it self-draining and breathable, this ensures rapid passage of the water and makes it quick drying. It has excellent resistance to weathering, humidity and temperature changes, also thanks to the addition of anti-UV stabilisers that prevent and slow down natural ageing without the addition of substances dangerous to the environment or to health. Maintenance: It is important to regularly clean the fabric in order to maintain its appearance in the best conditions and to extend its life. Dust and dirt wear out the fabric, so it is recommended to clean it with low suction vacuum cleaners, preferably once a week. Non-grease stains are eliminated by gently dabbing them with a clean cloth that leaves no residue or a sponge immersed in clean hot water and then well squeezed. If necessary, wash by dipping the cloth used for cleaning in soapy water or water with the addition of liquid dishwashing detergent (see formulas). Then dab

the surface with clean warm water, letting it dry completely. For grease stains, it is possible to use dry stain removers, scrupulously following the manufacturer's instructions. Do not use hot steam, do not dry with electrical appliances with temperatures above 50°C. Do not use abrasive substances or chemical solvents.

In case of doubt, test the cleaning product on a part hidden from view to verify the result, waiting at least 24 hours for any problems to arise.

Formulas: The soapy solution consists of 1/4 dl of soap flakes for each litre of hot water, which then needs to be cooled before use. The solution with liquid dishwashing detergent consists of up to 1 teaspoon of detergent per litre of water. If you use concentrated products, pour only a few drops into each litre of product.

Leather, hard leather:

Take care not to place products in direct sunlight as this can alter the colour of these materials. Avoid exposing the materials to heat sources.

Regularly dust using a soft, dry cloth. Any stains need to be removed as quickly as possible to prevent them from soaking in deeply. Use absorbent paper or a cloth to absorb them straight away. For cleaning, use specific, high-quality leather cleaning products and comply with the manufacturer's instructions as closely as possible.

If you have any doubts, test the cleaning product on a discreet area in order to check its effect. Wait for at least 24 hours to see if any problems arise. Alternatively, use a cloth that has been dampened with some water and well-diluted neutral soap. Do not rub. Instead, delicately dab the stain working from the edge into the centre, then dry immediately after treatment.

Wood:

Dust and common domestic stains can be removed using a solution made from water and well-diluted neutral soap. Under no circumstances should you use commercial stain removers for cleaning. In order to avoid scratching the products, use a soft cloth and clean using circular movements. Do not use solvents or abrasive products. Always dry surfaces using a dry cloth. If you have any doubts, test the cleaning product on a discreet area in order to check its effect. Wait for at least 24 hours to see if any problems arise.

Wood for outdoor use:

Wood is a natural material suitable for outdoor use. For a sustainable approach, Arper selects only essences from Europe within an FSC certified chain of custody. The use of water-based paints, safe for health and the environment, guarantees a high level of protection and durability for outdoor use, with a reduced

Care instructions

environmental impact.

Maintenanace: Dust and the most common stains can be removed using a well-diluted solution of water and neutral soap. It is absolutely necessary not to use commercial stain removers for cleaning. To avoid scratching, use a soft cloth and clean with gentle, circular movements (especially the opaque finishes, if subjected to action that is too aggressive, may develop shiny halos in spots). Do not use waxes for furniture or floors, solvents or abrasive products. Always dry the surfaces with a dry cloth. Do not use the pressure washer or high-pressure water, which may damage the surface of the wood. In case of doubt, test the cleaning solution on a part hidden from view to verify the result, waiting at least 24 hours for any problems to arise. Immediately remove any liquids spilled on the surface of the wood, avoid the accumulation of water or other liquids that could damage the product.

Wood can have impurities and imperfections, which fall within accepted quality standards, and should be considered as distinctive features that attest to its natural beauty. Periodic and correct maintenance extends the life of the product.

Plastic Materials:

Regularly plastic surfaces dust using a microfibre cloth. Dust and common domestic stains can be removed using a cloth or sponge that has been dampened in tepid water or water with some well-diluted neutral detergent in it.

Do not use commercial stain removers or aggressive products for cleaning. In order to avoid scratching the products, use a soft cloth and clean using circular movements. Under no circumstances should you use solvent-based detergents or abrasive products. If you have any doubts, test the cleaning product on a discreet area in order to check its effect. Wait for at least 24 hours to see if any problems arise.

Chrome-plated, anodised or painted metal surfaces:

Clean using specific products such as regular detergents for domestic surfaces diluted in tepid water, provided they are not abrasive and do not contain acid or bleach. Avoid using sponges and scourers made from synthetic fibre or metal as these could permanently mark surfaces. After cleaning, rinse products carefully to prevent traces of detergent from reacting with the surface finish to avoid dulling or oxidisation. After cleaning, dry with a shammy cloth. The use of polish on chrome-plated or painted surfaces is not recommended. These products should always be used with caution and only be experts as their abrasive qualities could irreparably damage surfaces. If you have any doubts, test the cleaning product on a discreet area in order to check its effect. Wait for at least 24 hours to see if any problems arise.

Stainless steel:

Clean on a regular basis (every 15-20 days) using a soft damp cloth or common products specific for stainless steel.

Table Tops:

Clean and remove any substance that accidentally comes into contact with the surface as quickly as possible using a damp cloth or microfibre cloth and some neutral detergent diluted in tepid water. Always dry after cleaning. Aggressive detergents containing bleach or abrasive detergents (such as bathroom cream cleaner) must never be used. Take care not to rub too hard in order to avoid scratching the surface. Avoid using sponges or scourers made from synthetic fibres or metal.

If you have any doubts, test the cleaning product on a discreet area in order to check its effect. Wait for at least 24 hours to see if any problems arise.

Glass surfaces

The tempered glass used by Arper ensures high levels of safety. In the event of a breakage, the glass smashes into tiny, rounded fragments which will not cause a cut. In any case, you should avoid hitting the glass with hard or sharp objects and the glass should not be exposed to extreme shifts in temperature (i.e. do not place very hot or cold items on it).

Regularly dust glass using a microfibre cloth. Clean using specific products or neutral soap applied using a soft, clean cloth. Do not used powered detergents or abrasive detergents that could scratch the glass, causing irrevocable damage to the surface. If you have any doubts, test the cleaning product on a discreet area in order to check its effect. Wait for at least 24 hours to see if any problems arise.

Marble and Venetian Terrazzo surfaces:

Clean and remove any substance that accidentally comes into contact with the surface as quickly as possible using a damp cloth or microfibre cloth and some tepid water or a specialist detergent. Always dry immediately after cleaning. Take care not to rub too hard in order to avoid scratching the marble. If you have any doubts, test the cleaning product on a discreet area in order to check its effect. Wait for at least 24 hours to see if any problems arise.

Marble is a calcareous, porous material that is susceptible to reactions with acidic substances. Marble can absorb fatty or oily substances and colourants. These can soak into the material and stain the surface. During use, you are advised against using objects that can scratch or cause abrasions to the surface, such as acidic products (Coca Cola, vinegar, acidic detergents) and colourants (wine, coffee, fruit, sugary liquid, tomato sauce, very hard water etc.).



Care instructions

Indications for use & maintenance of "outdoor" products:

Arper guarantees, through laboratory tests, the strength and durability of its products. It should be noted, however, that any material exposed to atmospheric agents and the elements, even if treated specifically for outdoor use, will undergo a gradual deterioration over time, the extent of which is closely related to the geographical position, the evolution of climatic phenomena, the more or less marked presence of humidity, salinity (poolside, marine environments).

Use and maintenance are conditions that determine the actual yield and maintenance in good condition of the product over time. It is therefore recommended to avoid critical external conditions such as prolonged and direct exposure to sunlight, pouring rain and aggressive environments such as proximity to the seaside or where the sea breeze can bring high levels of moisture with marine salinity or abrasive sands. Do not place wooden products on lawns or uneven surfaces, where any stagnation of water may damage the parts in contact. In any case, never let water or other liquids stagnate on the product. In the vicinity of plants or trees, remove any leaves, flowers or organic substances that could rest on the surfaces of the product, to prevent that their deterioration stains the paints or fabrics. In case of exposure to rain, as soon as possible, remove the pillows (if any) from the chair and let them dry separately to facilitate drying and drainage of the water. Periodic cleaning is recommended, following the recommended indications for the different materials. For short periods when the product is not in use, it is recommended to cover it with the protective cover. In case of prolonged non-use or during the winter period, it is recommended to clean the product, allow it to dry well, and store it in a well-aerated indoor place, protected from the elements. The pillows (if any) must be removed from the chair, cleaned and left to dry well, and finally, stored in a well-aerated indoor place, protected from the elements.

I colori visualizzati sono puramente indicativi e possono variare rispetto alla realtà. Rivolgersi ad Arper o al proprio rivenditore di fiducia per ricevere un campione colore o per maggiori informazioni.

Arper SPA si riserva di apportare modifiche e/o migliorie di carattere tecnico ed estetico ai propri modelli e prodotti in qualsiasi momento e senza preavviso.

Per maggiori informazioni visitate il sito arper.com

Colours shown are used for reference only and may look different in reality. Please contact Arper or your retailer to receive a colour sample or more information.

Arper SPA reserves the right to make modifications and improvements of a technical or aesthetic nature to the products at any time without notice.

For further information, please visit arper.com

Bei den angezeigten Farben handelt es sich um reine Farbbeispiele, die von der Realität abweichen können. Für Farbmuster und nähere Informationen wenden Sie sich bitte an Arper oder an den Händler Ihres Vertrauens. Arper SPA behält sich das Recht vor, jederzeit und ohne Vorankündigung Veränderungen und Verbesserungen technischen und ästhetischen Charakters an seinen Produkten vorzunehmen. Für weitere Informationen besuchen Sie bitte unsere Webseite arper.com

La reproduction photographique des couleurs n'est que purement indicative et peut être différente de la réalité. S'adresser à Arper ou à votre revendeur de confiance pour recevoir un échantillon de couleur ou pour de plus amples informations.

Arper SPA se réserve le droit d'apporter des modifications et/ou des améliorations d'ordre technique et esthétique à ses produits, et ceci à tout moment et sans préavis.

Pour plus d'informations, rendez-vous sur le site arper.com

Los colores visualizados son meramente indicativos y pueden diferir de la realidad. Para recibir una muestra del color o para más información, contactar a Arper o a su distribuidor de zona. Arper SPA se reserva el derecho de realizar cambios y/o mejoras técnicas y estéticas en sus productos en cualquier momento y sin previo aviso.

Para más información, visite arper.com"



<u>Italy</u>

Monastier (TV) — Headquarters and showroom Arper SPA Via Lombardia 16 31050 Monastier di Treviso (TV) T +39 0422 7918 F +39 0422 791800 info@arper.com www.arper.com

Commerciale Italia T +39 0422 791905 F +39 0422 791900 commerciale@arper.com

Export Office sales@arper.com

Milan — Showroom Via Pantano 30 20122 Milan T +39 02 89093865 milano@arper.com

EUROPE

<u>UK</u>

London — Subsidiary and showroom Arper UK LTD 11 Clerkenwell Road London EC1M 5PA T +44 (0) 20 7253 0009 london@arper.com

Germany

Cologne — Showroom Design Post Köln Deutz-Mülheimer-Str. 22a 50679 Köln T +49 221 690 650 info@designpost.de

Fruchtof München — Meeting Hub 2. Innenhof, 2. Etage Gotzinger Straße 52b D-81371 München T+49 171 1080976 muenchen@arper.com

<u>Norway</u>

Oslo — Showroom Drammensveien 130 0277 Oslo T +47 908 202226 norway@arper.com

Sweden

Stockholm — Branch T +46 705 101216 sweden@arper.com

The Netherlands

Amsterdam — Showroom Design Post Cruquiusweg 111-L 1019 AG Amsterdam T +31 (0)20 705 1555 showroom@beltane.nl

AMERICA

USA

New York — Subsidiary and showroom Arper USA Inc. 476 Broadway, Suite 2F NY 10013 New York T +1 (212) 647 8900 infousa@arper.com

Chicago — Showroom The Merchandise Mart Space#346 - 3rd Floor Chicago T +1 (336) 434 2366 infousa@arper.com

High Point, North Carolina — Production and logistics site 660 Southwest St High Point, NC 27260 T +1 (336) 434 2370 F +1 (212) 647 8912 infousa@arper.com

Los Angeles — Showroom 550 South Hope St., Suite 275 90071 Los Angeles T +1 (336) 434 2382 infousa@arper.com

<u>Mexico</u>

Mexico City — Subsidiary and showroom Culiacan 123, Piso 9 Col. Hipodromo Condesa Delegation Cuauhtémoc 06170 – Ciudad de México Mexico T +52 1 62714417 T +52 1 62714419 infolatam@arper.com

ASIA

<u>Japan</u>

Arper Japan K.K. — Subsidiary and showroom HT Jingu Gaien Bldg.8F Minato-ku Kita-Aoyama 2-7-22 Tokyo 107-0061 T +81 3 5775 0008 F +81 3 5775 0009 carejpn@arper.com

China

Shanghai — Subsidiary 爱尔派 (上海) 家具设计有限公司 Shanghai – China china@arper.com

Singapore

Singapore — Branch c/o 3 Lim Teck Kim Road, #01-01 Genting Centre 088934 Singapore singapore@arper.com

UAE

Arper Middle East — Subsidiary and showroom U-Bora Towers - Unit 1901 Business Bay Dubai T +971 529255633 infome@arper.com

